







# PowerFlex 527 Incremental Encoder Input

Catalog Number: 25-ENC-2




Wait three minutes  
after shutdown for  
capacitors to discharge  
to safe voltage levels.

## 3 Align Tabs of Encoder with the slots on the Control Module




## 4 Press Down Firmly to Lock Incremental Encoder onto the Control Module





**5****How to Remove the Encoder**

Hold the top of the encoder firmly











Pull out the encoder as shown

**IMPORTANT** Do not remove the encoder from the bottom as it might damage the encoder and the locking mechanism on the control module.**6****Wiring the Incremental Encoder**

Maximum Wire Size	Minimum Wire Size	Torque
2.08 mm <sup>2</sup> (14 AWG)	0.08 mm <sup>2</sup> (28 AWG)	0.18...0.22 Nm (1.56...1.9 lb-in)

No.	Signal	Description
A	Encoder A	Single channel, pulse train or quadrature A input.
A-	Encoder A (NOT)	
B	Encoder B	Quadrature B input.
B-	Encoder B (NOT)	
Z	Marker Z	Marker pulse
Z-	Marker Z (NOT)	
Cm	Power Return	Internal power source 250 mA (isolated).
+V	5...12V Power <sup>(1)</sup>	
①	Output	DIP switch selects 12 or 5 volt power supplied at terminals "+V" and "Cm" for the encoder.

I/O	Connection Example	I/O	Connection Example
<b>Encoder Power – Internal Drive Power</b>		<b>Encoder Power – External Power Source</b>	
			
<b>Encoder Signal – Single-Ended, Dual Channel</b>		<b>Encoder Signal – Differential, Dual Channel</b>	
			

(1) If Encoder requires 24V power, it must be supplied by an external power source.

U.S. Allen-Bradley Drives Technical Support - Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, E-mail: support@drives.ra.rockwell.com  
Online: <http://www.ab.com/support/abdrives>Rockwell Automation maintains current product environmental information on its website at  
<http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>

Allen-Bradley, Rockwell Software, Rockwell Automation, PowerFlex, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

**www.rockwellautomation.com****Power, Control and Information Solutions Headquarters**Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444  
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleeflaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640  
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846