

INSTALLATION INSTRUCTIONS

R-3W-DR-C6 Door Mount Isolation Kit

INSTALLATION:

1. Conduit - Seal cap
- Connector - Oval clip

2. Push seal cap onto end of conduit to achieve IP68.

3. For ease of installation moisten seal cap with water.



4. Push conduit with seal cap fully into connector. This guarantees the unique IP68/67 rating.



5. Install Retaining Oval Clip with access slot facing towards tubing, for future accessibility.



REMOVAL:

1. To re-open use a screwdriver.

INSTALLATION INSTRUCTIONS

R-3W-DR-C6 Door Mount Isolation Kit

INSTALLATION:

1. Conduit - Seal cap
- Connector - Oval clip

2. Push seal cap onto end of conduit to achieve IP68.

3. For ease of installation moisten seal cap with water.



4. Push conduit with seal cap fully into connector. This guarantees the unique IP68/67 rating.



5. Install Retaining Oval Clip with access slot facing towards tubing, for future accessibility.



- REMOVAL:
1. To re-open use a screwdriver.

INSTALLATION INSTRUCTIONS

R-3W-DR-C6 Door Mount Isolation Kit

INSTALLATION:

1. Conduit - Seal cap
- Connector - Oval clip

2. Push seal cap onto end of conduit to achieve IP68.

3. For ease of installation moisten seal cap with water.



4. Push conduit with seal cap fully into connector. This guarantees the unique IP68/67 rating.



5. Install Retaining Oval Clip with access slot facing towards tubing, for future accessibility.



REMOVAL:

1. To re-open use a screwdriver.

INSTALLATION INSTRUCTIONS

R-3W-DR-C6 Door Mount Isolation Kit

INSTALLATION:

1. Conduit - Seal cap
- Connector - Oval clip

2. Push seal cap onto end of conduit to achieve IP68.

3. For ease of installation moisten seal cap with water.



4. Push conduit with seal cap fully into connector. This guarantees the unique IP68/67 rating.



5. Install Retaining Oval Clip with access slot facing towards tubing, for future accessibility.



- REMOVAL:
1. To re-open use a screwdriver.